

MODEL: Linear1000F Gas Log Fire

LOG LOCATION GUIDE





LH LOG curved Top Front Edge

RH LOG



LOGS must be touching.

